

HT Box CR3 iTs


Data sheet hardware:

- Additional module dual channel: turbo / rail,
- On / off button
- Keys + / -
- 10 maps in memory: 0 > original, 1 > Minimum power, 9 Maximum power.
- Digital display map set,
- 1 power LED
- 2 LED + Turbo injection
- connector automotive,
- 150 cm cable plug & drive for Turbo + injection,
- Reprogrammable to change vehicle,
- Reprogrammable remotely via internet,
- With iTs system, for individual tuning to 100%.
- Interface for remote control cabin with on / off button + Map +/- Digital display (optional)

Features:

The CR3 ITS has 3 keys and 3 LED divided by function,

- Key 1 = on / off
- Key 2 = management maps (-)
- Key 3 = management maps (+)
- The display shows maps set (for about 3 seconds after selecting the program)
- USB port, used for reprogramming the software and create files iTs (usable after you install from the site HT MANAGER MAPPS).
- Red LEDs: LED 1 to the left of the button 2 shows the tuning current course of 'injection', and the LED 2 to the left of the button 3 indicates the current tuning of the turbo.



Using the remote control:

The digital technology of HT Box CR3 ITS, allows the memory command: for example, by setting the map 7, and activating the module, the processor will keep both the 'setting on, that the number of the selected map. By remote control, you can also change mapps.

Key function: A = on / B = off / C = mapp - / D= mapp +

Learning Remote Control:

The Key 1 also performs the learning function of the remote control.

To learn the remote control signal, follow this procedure:

- Press Key 1 (On / Off), and then give power supply to CR3 iTs by USB-door or by 24-pin main connector, at this point the red LEDs flash, now leave Key 1.
- Press Key A on remote control.
- When red lights stop flashing, signal has been learned.



Setting the programs:

The construction of the digital module allows you to choose the program that best fits the model of car, engine capacities and preferences of users.

To select the program, you have to remove the lid of the box.

There are three buttons, one to turn off and on, and two to increase or decrease the power:

- Key 1: On / Off
- Key 2: -
- Key 3: +

The program selected is shown on the display, which will remain on for 3 seconds, then map change.

The program zero is equivalent to the original program 1 minimum power, maximum power program 9.

After installing the module, and after checking the proper connections, the engine can be started.

If necessary, the program can be modified online.

Remote interface for the passenger compartment:

as an option, is available the 'remote interface for cockpit, it allows to activate and deactivate HT Box CR3 iTs from interior, and to set the maps.

software:

The software CR3 iTs, has a dual function:

1 read and write maps.

2 iTs generate files, these files allow our tuners to set properly tuning files for turbo and injection.

Files can be easily exchanged by mail, and customized for the customer today and in the future (the software update service is included only with the first car).



Support – customer care: info@house-tuning.de – Tel support: 0039-(0)6/9598098 – www.House-Tuning.de